

AT&T CopperLine Installation Manual

AT&T CopperLine Panels

Snap-in Blank Patch Panels for Straight Jacks

AT&T P/N 13x00NV0xxA-SB1U

Mount the panel onto a suitable rack



Assemble the front and back supports as needed
Shielded panels must be bonded to the rack with the grounding wire

Snap the terminated jacks into the blank panel ports from the back side



Snap the horizontal cables into the back support tray



Insert the modular cords into the ports and use the front rings support as needed



Avoid bending, kinking or twisting the horizontal cables and the modular cords

AT&T Authorized Licensee. AT&T, the AT&T Globe Design and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property and/or AT&T affiliated companies.
Issue 1.1 19/03/2013