

AT&T FiberLine Installation Manual

AT&T FiberLine Panels

High-Density MTP or MPO Cassette Fiber Optic Panel

AT&T P/N 27x00NV120A-BK1U

Use cable ties and cable retainers to route and hold the cables both in the front and in the back of the panel, avoiding any damage to the fibers.

Panel Front



Panel Back



Kit Contents: cable holder, cables ties, cable retainers.
All ties and retainers must be used properly, avoiding damage to the fibers.

AT&T Authorized Licensee. AT&T, the AT&T Globe Design and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property and/or AT&T affiliated companies.

Issue 1.1 19/03/2013